# Seaman Safety



## SEAMAN SAFETY LEISURE LIFERAFT





# ANYTIME ANYWHERE YOUR PARTNER AT SEA

### PRODUCTS

- SEAMAN LEISURE LIFERAFT / Valise 4 MAN
- SEAMAN LEISURE LIFERAFT / Canister 4 MAN
- SEAMAN LEISURE LIFERAFT / Valise 6 MAN
- SEAMAN LEISURE LIFERAFT / Canister 6 MAN
- SEAMAN LEISURE LIFERAFT / Valise 8 MAN
- SEAMAN LEISURE LIFERAFT / Canister 8 MAN
- SEAMAN LEISURE LIFERAFT / Valise 10 MAN
- SEAMAN LEISURE LIFERAFT / Canister 10 MAN

# Seaman Safety

Seaman Safety organization has been activated with the founder membership of Seaman Deniz Malz. Ltd. Sti., which was established by Capt. Koray Yeniay on August 2008. Seaman safety is giving a high quality, reliable and solution focused service to valuable shipowners and ship managers all around the world.

With 22 country distributor and 150 service point, organization wended a lot in 2 years. Target for 2011 is reach to 40 country distributors and 200 service points.

For supplying reliable and qualified service to shipowners, organization is making training, sessions 3 times a year for his members. By this way both the quality of serives are improved and the standarts of members as they get authorizations from more safety equipment manufacturers.

By making agreements with major safety equipment manufacturers, organization both helps these manufacturers on establishing global service network, and make the manufacturers to produce equipments with Seaman name which creates a Brand name for members.

The best example for that is the SEAMAN brand liferafts that started manufacturing at 2010. Organization has finished the manufacturing process of Seaman brand liferafts with cooperation of honored Shanghai Haian Lifesaving Equipments in Shanghai China, and started to renew the old liferafts of our valuable shipowners with brand new SEAMAN liferafts according to the fleet agreements made.

Organization is planing to finish manufacturing process of all Fire&Safety equipments requested by vessel, till August 2016. Established as a reaction to the monopolization of similar organizations, Seaman Safety

Organizations offers both freedom to his members and solution partnership to shipowners in all seas.



Туре	SEAMAN - Valise	Carrying capacity	4 man	
Physical form	square	Length(mm)	1520	
Width(mm)	1520	Heght(mm)	1100	
Packing size(mm)	650x220x420	Weight(≤kg/unit)	26	

### Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

#### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	1
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Canister	Carrying capacity	4 man	
Physical form	square	Length(mm)	1520	
Width(mm)	1520	Heght(mm)	1100	
Packing size(mm)	700x500x300	Weight(≤kg/unit)	30	

### Installation of liferaft on board

Ensure that if it is deck mounted, the top is facing upwards, instruction label is clearly visible. If pushpit mounted, ensure that the printer line is on the top side.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	1
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Valise	Carrying capacity	6 man	
Physical form	square	Length(mm)	1800	
Width(mm)	1800	Heght(mm)	1250	
Packing size(mm)	660x240x430	Weight(≤kg/unit)	30	

### Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~ 45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person
2 Paddles 1 Repair kit 1 Fishing kit 1 Heliograph(signal mirror) 1 Graduated drink cup

#### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	1
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Canister	Carrying capacity	6 man	
Physical form	square	Length(mm)	1800	
Width(mm)	1800	Heght(mm)	1250	
Packing size(mm)	700x500x300	Weight(≤kg/unit)	35	

### Installation of liferaft on board

Ensure that if it is deck mounted, the top is facing upwards, instruction label is clearly visible. If pushpit mounted, ensure that the printer line is on the top side.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	1
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Valise	Carrying capacity	8 man	
Physical form	square	Length(mm)	2030	
Width(mm)	2030	Heght(mm)	1250	
Packing size(mm)	750x280x450	Weight(≤kg/unit)	35	

### Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

#### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	2
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Canister	Carrying capacity	8 man	
Physical form	square	Length(mm)	2030	
Width(mm)	2030	Heght(mm)	1250	
Packing size(mm)	800x500x300	Weight(≤kg/unit)	40	

### Installation of liferaft on board

Ensure that if it is deck mounted, the top is facing upwards, instruction label is clearly visible. If pushpit mounted, ensure that the printer line is on the top side.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	2
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Valise	Carrying capacity	10 man
Physical form	square	Length(mm)	2255
Width(mm)	2255	Heght(mm)	1250
Packing size(mm)	N/A	Weight(≤kg/unit)	N/A

### Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

#### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	3
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.



Туре	SEAMAN-Canister	Carrying capacity	10 man
Physical form	square	Length(mm)	2255
Width(mm)	2255	Heght(mm)	1250
Packing size(mm)	900x530x320	Weight(≤kg/unit)	55

### Installation of liferaft on board

Ensure that if it is deck mounted, the top is facing upwards, instruction label is clearly visible. If pushpit mounted, ensure that the printer line is on the top side.

### Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

### **Righting of liferaft**

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

### **Boarding the liferaft**

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

#### Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

Liferaft specification
Double tube, self erecting canopy(Solas
approved materials)
High visibility orange waterproof Nylon
canopy with reflective tapes
Rainwater collection system
Look out port
Air circulating window
External canopy top mounted light and
interior light
Thermo insulated floor
4x30 litre stability water pockets
Rescue quoit with 30 metres line
Sea anchor
Inflatable boarding ladder
2 step weighted boarding ladder
1 Floating knife
Vacuum packed
Valise or canister

Emergency pack
3 Red hand flares
1 Waterproof signal torch
1 Bailer
2 Sponges
1 Whistle
1 Hand pump
1 Lifesaving signal card
4 Rubber leak stoppers
2 Paddles
1 Repair kit
1 Fishing kit
1 Heliograph(signal mirror)
1 Graduated drink cup
6 Seasickness pills/per person

#### **Spare Parts**

No	Description	Unit	Quantity	No	Description	Unit	Quantity
1	Red hand flares	рс	3	14	Repair fabric	рс	4
2	Signal torch + batteries	рс	1	15	Brush	рс	1
3	Bailer	рс	1	16	Sanding paper	рс	1
4	Sponge	рс	2	17	Scissors	рс	1
5	Whistle	рс	1	18	Paddle	рс	2
6	Life Saving signals	рс	1	19	Buoyant rescue line + quoit	set	1
7	Bellows pump	рс	1	20	Floating safety knife	рс	1
8	Leak stoppers	рс	4	21	Sea anchor	рс	1
9	Instruction manual	leaflet	1	22	External and internal lights	set	1
10	Fishing kit	set	1	23	Sea sickness tablet	pack	6рр
11	Graduated drink cup	рс	1	24	Water collecting bag	рс	3
12	Heliograph(signal mirror)	рс	1	25	Spare torch batteries	set	1
13	Adhesive	рс	1				

The WARRANTY is VOID if the liferaft is NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.

Address: Seaman Deniz Malzeme Ltd. Sti. Postahane Mh. Ankara Mercan Bahar Sok. No:5 34940 Tuzla / ISTANBUL – TURKEY Phone: +90 (216) 4473571 / +90 (216) 4473572 Fax: +90 (216) 4473141 Web: www.seamansafety.com Email: info@seamansafety.com

