

Seaman Safety



SEAMAN SOLAS TYPE LIFERAFTS

ANYWHERE

ANYTIME

YOUR PARTNER AT SEA

SEAMAN SOLAS TYPE LIFERAFTS

PRODUCTS

- SEAMAN SOLAS TYPE LIFERAFTS – A/T
6 PERSON (THROW OVERBOARD)
- SEAMAN SOLAS TYPE LIFERAFTS – A/T
10 PERSON (THROW OVERBOARD)
- SEAMAN SOLAS TYPE LIFERAFTS – A/T
15 PERSON (THROW OVERBOARD)
- SEAMAN SOLAS TYPE LIFERAFTS – A/T
16 PERSON (THROW OVERBOARD)
- SEAMAN SOLAS TYPE LIFERAFTS – A/T
20 PERSON (THROW OVERBOARD)
- SEAMAN SOLAS TYPE LIFERAFTS – A/T
25 PERSON (THROW OVERBOARD)

- SEAMAN SOLAS TYPE LIFERAFTS – D
15 PERSON (DAVIT LAUNCHABLE)
- SEAMAN SOLAS TYPE LIFERAFTS – D
16 PERSON (DAVIT LAUNCHABLE)
- SEAMAN SOLAS TYPE LIFERAFTS – D
20 PERSON (DAVIT LAUNCHABLE)
- SEAMAN SOLAS TYPE LIFERAFTS – D
25 PERSON (DAVIT LAUNCHABLE)

Seaman Safety organization has been activated with the founder membership of Seaman Deniz Malz. Ltd. Sti., which was established by Capt. Koray Yeniay on August 2008. Seaman safety is giving a high ality, reliable and solution focused service to valuable shipowners and ship managers all around the world.

With 22 country distributor and 150 service point, organization wended a lot in 2 years. Target for 2011 is reach to 40 country distributors and 200 service points.

For supplying reliable and qualified service to shipowners, organization is making training, sessions 3 times a year for his members. By this way both the quality of serives are improved and the standarts of members as they get authorizations from more safety equipment manufacturers.

By making agreements with major safety equipment manufacturers, organization both helps these manufacturers on establishing global service network, and make the manufacturers to produce equipments with Seaman name which creates a Brand name for members.

The best example for that is the SEAMAN brand liferafts that started manufacturing at 2010. Organization has finished the manufacturing process of Seaman brand liferafts with cooperation of honored Shanghai Haian Lifesaving Equipments in Shanghai China, and started to renew the old liferafts of our valuable shipowners with brand new SEAMAN liferafts according to the fleet agreements made.

Organization is planing to finish manufacturing process of all Fire&Safety equipments requested by vessel, till August 2016. Established as a reaction to the monopolization of similar organizations, Seaman Safety

Organizations offers both freedom to his members and solution partnership to shipowners in all seas.

SEAMAN SOLAS TYPE LIFERAFT - A/T 6 PERSON



<i>Type</i>		SEAMAN – A/T 6 (Throw overboard)	<i>Raft height (mm) (exclude stabilization water pocket)</i>		1350
<i>Form of raft</i>		octagon			
<i>Capacity</i>		6 man	<i>Cylinder volume (l)</i>		2.5 (3)
<i>Tube diameter (mm)</i>	<i>Up tube</i>	233	<i>Gas(g)</i>	<i>CO₂</i>	1200
	<i>Down tube</i>	249		<i>NO₂</i>	100
<i>Raft length (mm)</i>		2160	<i>Storage canister</i>	<i>Dia.(mm)</i>	610
<i>Raft width (mm)</i>		2160		<i>Length(mm)</i>	1100
				<i>Weight(Kg)</i>	85

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT A/T 6 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - A/T 10 PERSON



Type		SEAMAN – A/T 10 (Throw overboard)	Raft height (mm) (exclude stabilization water pocket)	1450	
Form of raft		octagon			
Capacity		10 man	Cylinder volume (l)	3	
Tube diameter (mm)	Up tube	255	Gas(g)	CO₂	1800
	Down tube	295		NO₂	160
Raft length (mm)		2730	Storage canister	Dia.(mm)	684
Raft width (mm)		2730		Length(mm)	1150
				Weight(Kg)	120

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT A/T 10 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - A/T 15 PERSON



Type		SEAMAN – A/T 15 (Throw overboard)	Raft height (mm) (exclude stabilization water pocket)		1500
Form of raft		Regular twelve -side			
Capacity		15 man	Cylinder volume (l)		5
Tube diameter (mm)	Up tube	295	Gas(g)	CO ₂	2800
	Down tube	335		NO ₂	200
Raft length (mm)		3405	Storage canister	Dia.(mm)	700
Raft width (mm)		3405		Length(mm)	1300
				Weight(Kg)	140

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT A/T 15 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - A/T 16 PERSON



<i>Type</i>		SEAMAN – A/T 16 (Throw overboard)	<i>Raft height (mm) (exclude stabilization water pocket)</i>		1500
<i>Form of raft</i>		Regular twelve -side			
<i>Capacity</i>		16 man	<i>Cylinder volume (l)</i>		5
<i>Tube diameter (mm)</i>	<i>Up tube</i>	295	<i>Gas(g)</i>	<i>CO₂</i>	2800
	<i>Down tube</i>	335		<i>NO₂</i>	200
<i>Raft length (mm)</i>		3405	<i>Storage canister</i>	<i>Dia.(mm)</i>	700
<i>Raft width (mm)</i>		3405		<i>Length(mm)</i>	1300
				<i>Weight(Kg)</i>	140

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT A/T 16 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - A/T 20 PERSON



Type		SEAMAN – A/T 20 (Throw overboard)	Raft height (mm)(exclude stabilization water pocket)		1650
Form of raft		Long eight-side			
Capacity		20 man	Cylinder volume (l)		6
Tube diameter (mm)	Up tube	302	Gas(g)	CO₂	3500
	Down tube	350		NO₂	240
Raft length (mm)		4280	Storage canister	Dia.(mm)	737
Raft width (mm)		3080		Length(mm)	1500
				Weight(Kg)	175

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT A/T 20 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - A/T 25 PERSON



Type		SEAMAN – A/T 25 (Throw overboard)		<i>Raft height (mm) (exclude stabilization water pocket)</i>	1800	
<i>Form of raft</i>		Long eight-side				
<i>Capacity</i>		25 man		<i>Cylinder volume (l)</i>		
<i>Tube diameter (mm)</i>	<i>Up tube</i>	320	<i>Gas(g)</i>	<i>CO₂</i>	4500	
	<i>Down tube</i>	372		<i>NO₂</i>	300	
<i>Raft length (mm)</i>		4700		<i>Storage canister</i>	<i>Dia.(mm)</i>	
<i>Raft width (mm)</i>		3450			<i>Length(mm)</i>	1500
					<i>Weight(Kg)</i>	195

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT A/T 25 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - D 15 PERSON



Type		SEAMAN – D 15 (David launchable)		Raft height (mm) (exclude stabilization water pocket)	1750	
Form of raft		Rectangular ten-side				
Capacity		15 man		Cylinder volume (l)		
Tube diameter (mm)	Up tube	290		Gas(g)	CO ₂	3200
	Down tube	340			NO ₂	200
Raft length (mm)		3400		Storage canister	Dia.(mm)	700
Raft width (mm)		3400			Length(mm)	1300
					Weight(Kg)	170

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT D 15 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - D 16 PERSON



Type		SEAMAN – D 16 (David launchable)		Raft height (mm) (exclude stabilization water pocket)	1750	
Form of raft		Rectangular ten-side				
Capacity		16 man		Cylinder volume (l)		
Tube diameter (mm)	Up tube	290		Gas(g)	CO ₂	3200
	Down tube	340			NO ₂	200
Raft length (mm)		3400		Storage canister	Dia.(mm)	700
Raft width (mm)		3400			Length(mm)	1300
					Weight(Kg)	170

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT D 16 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - D 20 PERSON



Type		SEAMAN – D 20 (David launchable)		Raft height (mm) (exclude stabilization water pocket)	1700	
Form of raft		Rectangular ten-side				
Capacity		20 man		Cylinder volume (l)		
Tube diameter (mm)	Up tube	310		Gas(g)	CO ₂	3800
	Down tube	350			NO ₂	260
Raft length (mm)		3825		Storage canister	Dia.(mm)	737
Raft width (mm)		3825			Length(mm)	1500
					Weight(Kg)	185

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT D 20 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

SEAMAN SOLAS TYPE LIFERAFT - D 25 PERSON



Type		SEAMAN – D 25 (David launchable)		<i>Raft height (mm) (exclude stabilization water pocket)</i>	1800	
<i>Form of raft</i>		Long twelve-side				
<i>Capacity</i>		25 man		<i>Cylinder volume (l)</i>		
<i>Tube diameter (mm)</i>	<i>Up tube</i>	335		<i>Gas(g)</i>	<i>CO₂</i>	4700
	<i>Down tube</i>	370			<i>NO₂</i>	400
<i>Raft length (mm)</i>		4530		<i>Storage canister</i>	<i>Dia.(mm)</i>	737
<i>Raft width (mm)</i>		3730			<i>Length(mm)</i>	1500
					<i>Weight(Kg)</i>	220

Installation of liferaft on board

- The valise liferaft should be stowed in a place clearly marked so it can be accessed quickly and easily. Do not stow in a place where it might become inaccessible due to other items being placed on top.
- Valises should be stored protected from exposure to saltwater.

Activation of liferaft

Before deployment, ensure that the following is carried out:

- Ensure liferaft painter line is securely tied to the vessel
- Everyone should put on their lifejackets
- Collect any extra safety equipment such as food, water, clothes etc...
- Throw the liferaft overboard to the opposite direction to the wind and then pull firmly on the painter to inflate the liferaft.

Inflation time is from 15 sec ~45 sec (depending on temperature)

Righting of liferaft

If the liferaft inflates upside down, use the righting strap located on the bottom of the liferaft in order to turn it over. Position the raft with the gas cylinder in the leeward position before attempting to turn it over into its correct position.

Boarding the liferaft

- Try to board the liferaft directly from your vessel. If possible, you should avoid entering the water.
- If someone fails to board the liferaft directly from the vessel and falls into the water, they can use the rope ladder to board.
- Once you confirmed that all crew members are on board, cut the painter line, using the knife provided (to be found inside by the entrance). Use the 2 paddles provided in the emergency pack in order to get away as quickly as possible from the sinking boat.
- Deploy the sea anchor in order to increase the stability of the liferaft at sea.
- Close the entrance in heavy/cold weather.
- All crew members to take seasick tablet as per instructions. Keep calm, save energy.

Maintaining & repairing the liferaft

- Keep the liferaft clean and dry, for this purpose, use the bailer and sponges.
- Carefully check the pressure of the buoyancy tubes and make sure the tubes are always firm. If need, use the pump provided to keep up the pressure.
- In case of a tube puncture, use the repair kit and adhesive provided, to repair it.
- Note that the both buoyancy tubes are independent. If one tube is punctured, the other tube will remain inflated, and keep the liferaft afloat.

Important tips

- Always ensure the liferaft servicing is up to date.
- Stow the liferaft at an easy accessible position.
- The external light is automatically activated when the liferaft is inflated. During daylight, turn off the light.
- Should someone fall overboard, use the rescue quoit with 30 m line in order to bring the survivor back on board.
- Dispose of all sharp objects.

CONTENTS OF SEAMAN SOLAS TYPE LIFERAFT D 25 AND EMERGENCY PACK			
Heaving Line	1	Dozen Per Person: Water (125 ml)	1
Floating Knife	1	Repair Kit	1
Bailer	1	Pump	1
Sponge	2	Repair plug set	1
Sea Anchor	2	Safety scissors	1
Paddles	2	Per Person: Sea sickness bags	1
Relief valve stopper kit	1	First Aid Kit	2
Label (contents)	1	Thermal Protective Aids	1
Can openers	3	Whistle	1
Drinking cup	1	Raft ID tube	1
Fishing kit	1	Signaling Mirror	1
Hand flares	6	Waterproof Flashlight w/ spare bulb	1
Per Person: Food Provisions	1	Life saving signal set	1
Rocket signals	4	Raft Manual	1
Smoke signals	2		

The WARRANTY is **VOID** if the liferaft is **NOT SERVICED AT AN APPROVED SEAMAN SERVICE STATION.**

Price:

**Address: Seaman Deniz Malzeme Ltd. Sti. Postahane Mh. Ankara Mercan
Bahar Sok. No:5 34940 Tuzla / ISTANBUL – TURKEY
Phone: +90 (216) 4473571 / +90 (216) 4473572
Fax: +90 (216) 4473141
Web: www.seamansafety.com
Email: info@seamansafety.com**